



**NOTE: REFER TO A.D.A. ACCESSIBILITY GUIDELINES FOR COMPLETE INSTALLATION REQUIREMENTS.**

**WOOD FLOOR INSTALLATION**

- 1- USING FIXTURE BASE (1) AS A TEMPLATE SCRIBE AND CUT-OUT FLOOR OPENING (2) REQUIRED.
- 2- POSITION FIXTURE BASE INTO OPENING AND SECURE TO FLOOR THROUGH 1/4" DIAMETER MOUNTING PUNCHING (3) WITH INSTALLER PROVIDED FLOOR ANCHORS AND ANCHORING HARDWARE.

**CEMENT FLOOR INSTALLATION**

- 1- USE FIXTURE BASE (1) AS A FORM AFTER GREASING OR OILING THE OUTSIDE OF THE BASE TO PREVENT THE FIXTURE FROM STICKING TO THE CONCRETE.
- 2- POSITION FIXTURE BASE INTO OPENING AND SECURE TO FLOOR THROUGH 1/4" DIAMETER MOUNTING PUNCHING (3) WITH INSTALLER PROVIDED FLOOR ANCHORS AND ANCHORING HARDWARE.

NOTE: FOR POURED FLOOR CONSTRUCTION, TEMPORARY BRACING SHOULD BE INSTALLED WITHIN FIXTURES OPENING (1) TO PREVENT DEFORMATIONS WHICH MAY OCCUR DURING POUR.

<p>ACORN ENGINEERING COMPANY P.O. BOX 3527 INDUSTRY, CA. 91744 (626) 336-4561 FAX (626) 961-2200</p>	<p>TITLE <b>WATERLESS TOILET STOOL CAT #2131-ADA</b></p>		
	<p>MANUFACTURE DATE</p> <p><b>JANUARY 1994</b></p> <p><b>TO PRESENT</b></p>	<p>DATE ISSUED</p> <p><b>03/25/94</b></p>	<p>DRAWING NUMBER</p> <p><b>9908-420-001</b></p>
		<p>DATE REVISED</p> <p><b>04/20/11</b></p>	