



*NOTE: SPECIAL SNAKE EYE DRIVER BIT (5) REQUIRED TO COMPLETE INSTALLATION NOT INCLUDED. REFER TO DRAWING 9951-001-001.

REFERENCE DRAWING	
SPECIAL TOOLS	9951-001-001

INSTALLATION INSTRUCTIONS:

1- USE PUNCHED MOUNTING HOLES ON UNIT (1) AS TEMPLATE AND MARK LOCATIONS OF ANCHORING POINTS FOR WALL ANCHORS (2). WALL ANCHORS (2) ARE BY OTHERS.

2- INSTALL WALL ANCHORS AS RECOMMENDED BY MANUFACTURER.

3- FASTEN UNIT (1) TO WALL USING TWO (2) 1/4-20 x 1" VANDAL RESISTANT, SPANNER-HEAD SCREWS PROVIDED (3).

NOTE: HOOK TENSION IS ADJUSTABLE BY TIGHTENING OR LOOSENING ADJUSTMENT SCREW (4).

<p>ACORN ENGINEERING COMPANY P.O. BOX 3527 INDUSTRY, CA. 91744 (626) 336-4561 FAX (626) 961-2200</p>	<p>TITLE FRONT MOUNT ACCESSORY, SINGLE ECONO CLOTHES HOOK CAT# 1830-ECH</p>	
	<p>MANUFACTURE DATE DECEMBER 1971 TO PRESENT</p>	<p>DATE ISSUED 04/01/04</p> <p>DATE REVISED 06/21/04</p>