



INSTALLATION INSTRUCTIONS:

- A- ASSEMBLE 3/8" NPT x 3/8" OD TUBE ELBOW (1) TO 3/8" PE TUBE PROVIDED (2). THREAD OVERFLOW INSERT (3) THROUGH OVERFLOW OPENING(S) IN BASIN AND HAND TIGHTEN THE INSERT (3) TO THE ELBOW ASSEMBLY.
- B- ASSEMBLE APPLICABLE WASTE CONNECTION (4) TO DRAIN OPENING AS SHOWN. NOTE: INTEGRAL DRAIN (5) REQUIRES NO ASSEMBLY.

NOTE: TEFLO N TAPE RECOMMENDED FOR ALL THREADED CONNECTIONS.

- C- FIT 3/8" OD PE TUBING (2) FROM OVERFLOW CONNECTION (1) TO OVERFLOW CONNECTION ON WASTE ASSEMBLY. NOTE: INSTALLER MAY CUT PE TUBING TO LENGTH. TIGHTEN 3/8" NPT x 3/8" OD TUBE CONNECTION PROVIDED (6) TO 3/8" OD PE TUBE (2). TIGHTEN TO (4) OR (5) WASTE ASSEMBLY AS SHOWN.