



INSTALLATION INSTRUCTIONS:

- A- INSERT LAVY STRAINER (1) INTO DRAIN OPENING. REACH THRU REAR ACCESS OPENING, AND SLIDE RUBBER GASKETS (2), DRAIN COLLAR (3), FOLLOWED BY THE FIBER GASKET (4) OVER THREADS OF THE STRAINER. THREAD THE 1-1/2" NUT (5) ONTO THE STRAINER ASSEMBLY AND TIGHTEN SNUGLY. INSTALL THE TUBE WASTE OUTLET CONNECTION (6) TO THE LAVY STRAINER ASSEMBLY FOLLOWED BY THE P-TRAP ASSEMBLY (7).
- B- FOR 8930 MODELS, ENSURE SUPPLIES PASS THRU SLOTS IN ACCESS PLATE (8) (VALVE BY OTHERS) WITH CONSIDERATION FOR DIMENSIONS SHOWN.
- C- ASSEMBLE ACCESS PLATE TO LAVY HOUSING WITH #10-32 SCREWS (9) AND TINNERMAN NUTS (10) PROVIDED.
- D- SECURE CENTERING STUD (11) 11-1/2" AWAY FROM FINISHED WALL WITH 1/4" SCREW (12), LOCK WASHER (13) AND FLAT WASHER (14) PROVIDED. FLOOR ANCHOR IS BY OTHERS.
- E- PLACE LAVY ON CENTERING STUD (11) AND MAKE UP WASTE AND SUPPLY CONNECTIONS.
- F- ANCHOR LAVY TO WALL WITH WALL ANCHORING HARDWARE (15) BY OTHERS.

MODEL 8930 SHOWN

NEO-METRO P.O. BOX 3527 • CITY OF INDUSTRY, CA 91744 USA 800-591-9050 • 626-855-4854 • www.neo-metro.com	TITLE METROPOLIS CONICAL BASIN MODEL # 8930 / 8931		
		MANUFACTURE DATE SEPTEMBER 1999 TO PRESENT	DATE ISSUED 09/13/99 DATE REVISED 09/20/04
			DRAWING NUMBER 9935-000-001