



INSTALLATION INSTRUCTIONS

- A- Assemble Overflow Insert ① to 3/8" NPT female elbow ② through punching in bowl.
- B- Apply plumbers putty between Strainer Tailpiece ③ and lavy as shown.
- C- Assemble Strainer Tailpiece ③, Rubber Gaskets ④, Overflow Adapter ⑤, Felt Washer ⑥ and Nut ⑦ as shown.
- D- Connect P-Trap Assembly ⑧ to Strainer Tailpiece ③.
- E- Assemble 3/8" NPT male connection ⑨ to Overflow Adapter ⑤.

TITLE		OPTIONAL -OF OVERFLOW WASTE ASSEMBLY	
MANUFACTURE DATE		DATE ISSUED	DRAWING NUMBER
FEBRUARY 2001 TO PRESENT		02/14/01	9935-008-001
		DATE REVISED 04/23/01	