



INSTALLATION INSTRUCTIONS:

A- REFER TO FOUNTAIN INSTALLATION INSTRUCTIONS FOR ADDITIONAL DETAILS.

B- CAREFULLY UNPACK CANE SKIRT AND HARDWARE. SEPARATE ENCLOSURE (1) FROM MOUNTING CHANNEL (2).

C- REMOVE BASIN SCREW (3) FROM FOUNTAIN (4) AND DISCONNECT RISER TUBING (5) FROM VALVE ASSEMBLY TO (6) BUBBLER AND SET BASIN ASIDE.

D- DISASSEMBLE MOUNTING CHANNEL (2) FROM SK4-18 ASSEMBLY AND USE MOUNTING CHANNEL AS A TEMPLATE.

E- CENTER MOUNTING CHANNEL (2) ON FOUNTAIN BY ALIGNING SLOT ON CHANNEL WITH P-TRAP SLOT (7) ON FOUNTAIN. ENSURE THAT CHANNEL IS FULLY TO THE REAR THEN LOCATE & MARK MOUNTING POINTS ON BOTTOM OF FOUNTAIN.

F- DRILL 1/4" CLEARANCE HOLES ON BOTTOM OF FOUNTAIN FOR #10-32 SCREWS (10) PROVIDED.

G- FASTEN MOUNTING CHANNEL (2) TO BOTTOM OF DRINKING FOUNTAIN (4) USING SCREWS PROVIDED FROM INSIDE CABINET.

H- SECURE SKIRT (1) TO MOUNTING CHANNEL (2) WITH SCREWS PROVIDED (8) TO COMPLETE THE INSTALLATION.