



INSTALLATION INSTRUCTIONS:

- A- ANCHOR STANCHIONS (1) TO FLOOR AT SPACING SHOWN USING HARDWARE (2) BY OTHERS THROUGH 9/16" DIAMETER HOLES IN FLOOR FLANGE AS SHOWN IN STANCHION FOOTPRINT.
- B- SECURE STUDS (3) THROUGH APPROPRIATE HOLES ONTO BOTH MOUNTING PLATES (4). TWO SMALL STUDS ON LOWER PLATE. TWO LARGER STUDS ON THE UPPER PLATE. USE NUTS AND WASHERS (8) ON FRONT AND BACK OF PLATE WITH STUDS PROTRUDING 1/2" MAXIMUM BEYOND FINISHED WALL FACE.
- C- ASSEMBLE BOTH PLATES (4) AT APPROPRIATE HEIGHTS TO STANCHIONS (1) USING SUPPLIED U-BOLTS (5) AND NUTS AND WASHERS (6) THROUGH 1/2" DIAMETER HOLES (7). U-BOLTS MAY NEED TO BE TRIMMED DEPENDING ON DEPTH OF FINISHED WALL MATERIAL.

- D- MAKE APPROPRIATE SUPPLY AND WASTE ROUGH-INS.
- E- COMPLETE INSTALLATION OF FINISHED WALL LEAVING STUDS (3) PROTRUDING AND ROUGH-INS ACCESSIBLE.
- F- SECURE MOUNTING BRACKET PROVIDED WITH COOLER TO THE UPPER STUDS (3) WITH NUTS & WASHERS (8). COMPLETE INSTALLATION REFERENCING THE FIXTURE INSTRUCTIONS.

<p>P.O. Box 3527 Industry, CA 91744 15125 Proctor Ave., City of Industry, CA 91746 (800) 453-7465 (626) 333-2543 www.murdockmfg.com</p>	<p>TITLE OPTIONAL -CSC2 SINGLE WATER COOLER CONCEALED SUPPORT CARRIER</p>		
	<p>MANUFACTURE DATE</p> <p>JUNE 2006</p>	<p>DATE ISSUED</p> <p>06/14/06</p>	<p>DRAWING NUMBER</p> <p>9938-321-001</p>
	<p>TO PRESENT</p>	<p>DATE REVISED</p> <p>08/14/12</p>	