




Acorn-Sinks® Installation Instructions - Drop-In Sinks

Scan QR Code to view Installation Video.





INSTALLATION STEPS

1. Position the sink upside down on the Countertop at desired location **[A]**.
Using a Marking Tool, carefully trace the outer edge of the Sink and create outline.
2. Mark a line offset **5/16"** **TO THE INSIDE** of the outline of the Sink **[B]**. Detail corners with a **1-1/2" Radius**.
NOTE: Do not cut square corners. The Cutaway area should be smaller than the original Sink outline.
3. Drill a pilot hole on the 4 corners of the **INSIDE** line.
Using an appropriate Saw, cut out Sink opening (*Caution: Cutaway portion will fall off*).



4. Apply Silicone Caulk (by others) to topside of Countertop along the cutout **[C]**.
5. Carefully lower Sink into cutout as shown in Figure **[D]**.
6. Assemble the Clips and Screws as shown in Figure **[F]**.
7. From the underside, place a Clip in the center along each side and hand tighten to hold Sink in place. Fasten the remaining Clips along the edge and space them approximately 3" [76] from each end and equally along the front, back, and sides as shown in Figure **[E]** (Clip quantity differs with Sink size).
8. Check the seal between the Sink and Countertop. Lightly tighten Clips evenly until the Sink is snug against the Countertop **[G]**. Do not over tighten. Wipe away any excess Caulking.



Verify all applicable Plumbing Code requirements prior to installation. Mounting Faucet to Sink prior to installation may reduce time and labor.
Note: For ADA Sink models: Compliance is subject to the interpretation and requirements of the Local Code Authority.

TECHNICAL ASSISTANCE TOLL FREE TELEPHONE NUMBER: 1-800-743-8259

ACORN ENGINEERING COMPANY

P.O. BOX 3527 • CITY OF INDUSTRY, CA 91744 U.S.A.
TOLL FREE 800-488-8999

Drawing # 9000-M00-002 12/04/23 A