

-AP

Auto-Purge Sensor Function Remote Controller

STANDARD FEATURES

- *Unique Auto-Purge Infra-red Sensor Allows for Customization of Multiple Settings*
- *Remote Controller Allows for Adjustment of Infra-red Sensor Functions*
- *Adjustable Auto-Purge Cycle and Duration*
- *Adjustable Infra-red Sensor Range Detection*
- *Adjustable Lock-Out Time Between Uses*

SPECIFICATIONS:

Specific Murdock[®] Bottle Filler and Faucet products with -SO Hands-Free Infra-red Sensor Control feature an Auto-Purge Sensor which allows adjustment of Purge Cycle, Sensor Range and Lock-out functions. The -AP Sensor Function Remote Controller provides for adjustment of the Auto-Purge Timing Cycle, Infra-red Sensor Detection Range and Activation Lock-out settings.

(Check product submittal for models provided with Adjustable Auto-Purge Sensor.)

Auto-Purge Settings are Factory pre-set to activate Bottle Filler and Faucet for 10 second duration which occurs 24 hours after the last activation of the Fixture.

Adjustment of Auto-Purge timed intervals include an "OFF" Setting or range from 1 Hour, 2, 3, 6, 12, 24, 36, and 72 Hours. Adjustable Flow Duration when Auto-Purge occurs includes range from 1 to 60 seconds, in 1 second increments.

Infra-red Sensor Range is Factory pre-set to suit fixture. Remote Controller allows Bottle Filler adjustment from 1/4" (6.4mm) to 2" (51mm) in 1/4" (6.4mm) increments. Faucet Sensor Range adjustments are possible from 2" (51mm) to 20" (508mm) in 1" (25mm) increments.

Lock-Out Setting provides lock-out time to activate fixture for 1, 2 or 3 minutes.



MODEL:

-AP Auto-Purge Sensor Function Controller

(Controller is shown with most common Sensor adjustments. Refer to Installation Manual for Complete Operating Details)

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov