



NOTES:

READ ALL INSTRUCTIONS THOROUGHLY. PANEL ASSEMBLY SHOULD NOT BE MOUNTED UNTIL FINISHED WALL HAS BEEN COMPLETED AND FIXTURE INSTALLED WITH HYDRAULIC FLUSH VALVE (1) PROVIDED. THE FLUSH VALVE ACCESS PANEL ASSEMBLY IS A FINISHED PRODUCT; EXERCISE CARE TO AVOID DAMAGING WALL FRAME/PANEL OR OTHERWISE MARRING POWDER COAT FINISH.

INSTALLATION INSTRUCTIONS:

- A-BLOCK OUT AND PROVIDE SUPPORT BACKING FOR WALL FRAME (2) USING BLOCKOUT DIMENSIONS (3) INDICATED. POSITION WALL FRAME (2) ON CENTERLINE OF FIXTURE WITH BOTTOM OF WALL FRAME 2-1/2" ABOVE INTEGRAL FLOOD RIM OR TOP OF URINAL.
- B-INSTALL FIXTURE AND CONCEALED HYDRAULIC FLUSH VALVE MAKING UP CONNECTIONS AS REQUIRED. REFER TO FIXTURE AND FLUSH VALVE MANUFACTURER INSTALLATION SHEETS FOR ADDITIONAL INFORMATION.
- C-REMOVE STAINLESS STEEL PANEL (4) AND INSTALL WALL FRAME (2) ONTO FINISH WALL. SECURE WITH ANCHORING HARDWARE PROVIDED BY THE INSTALLER THROUGH $\phi 1/4"$ x 1/2" LONG SLOTS (5) PROVIDED (8 PLACES).
- D-COMplete the installation by assembling panel (4) to installed wall frame (2) with hardware (6) provided.



ACORN ENGINEERING COMPANY
 P.O. BOX 3527 Industry, CA 91744
 15125 Proctor Ave Industry, CA 91746
 (626) 336-4561 FAX (626) 961-2200

TITLE LIGATURE RESISTANT, FLUSH VALVE ACCESS PANEL, LR2898		
MANUFACTURE DATE OCTOBER 2015 TO PRESENT	DATE ISSUED 12/13/23	DRAWING NUMBER 9908-392-001
	DATE REVISED	