



1 COMPLETE ASSEMBLY

1	2563-260-001	PLASTIC FLOOD-TROL ASSEMBLY COMPL.	18	2563-008-000	PILOT ORIFICE PLATE SPRING
2	2563-132-199	MOUNTING NUT	19	2563-009-001	PILOT ORIFICE PLATE ASSEMBLY
3	2563-130-002	RESET VALVE PUSHBUTTON ASSEMBLY	20	2563-010-001	WATER DIAPHRAGM ASSEMBLY
4	2160-007-199	1/4" O.D. x 7FT TUBING PE (CLEAR)	21	2570-027-000	LEFT HAND VALVE BODY
5	1895-103-001	3/8" x 3/16" UNION w/ GRIPPER ASSY.	22	2563-261-199	FLOOD-TROL FV MOUNTING BRACKET
6	1895-450-000	1/8" FERRULE NUT, PLASTIC	23	2563-129-000	FLOOD-TROL DECAL
7	2150-001-199	1/8" OD x 10" LOW DENSITY PE TUBING	24	2563-264-001	TEE ASSY w/ADAPTER FOR HYDRAULIC FT
8	2160-003-199	1/4" OD x 3 FEET LOW DENSITY PE TUBING	25	0401-015-000	O-RING
9	1895-102-000	1/4" O.D. TUDE UNION CONNECTOR	26	2570-045-000	SINGLE TEMP TEE BODY
10	2563-100-003	FLOOD-TROL VALVE ASSEMBLY	27	0401-014-000	O-RING
11	0116-012-000	8-32 x 1-1/4" PHILLIPS HEAD MS	28	2563-264-199	1/8" NPT ADAPTER
12	0331-003-000	#8 LOCKWASHER	29	1896-001-000	1/4" OD x 1/8" NPT ADAPTER
13	2563-114-000	COVER PLATE	30	0326-100-000	RETAINING CLIP
14	2563-121-001	DIAPHRAGM ASSEMBLY	31	0401-016-000	O-RING
15	2563-001-000	MOTOR HOUSING	32	2563-263-199	MOUNTING ADAPTER
16	0401-026-000	O-RING	33	0250-007-000	#10-32 x 1/2" STAINLESS STEEL SCREW
17	2563-002-199	SEPARATOR CUP	34	0116-011-000	#10-32 x 5/16" PHILLIPS RND HD SCREW
ITEM	PART NUMBER	DESCRIPTION	ITEM	PART NUMBER	DESCRIPTION

<p>ACORN ENGINEERING COMPANY P.O. BOX 3527 INDUSTRY, CA. 91744 (626) 336-4561 FAX (626) 961-2200</p>	<p>TITLE FLOOD-TROL MANUAL RESET ASSEMBLY - FRONT ACCESS -FA -FT</p>		
	<p>MANUFACTURE DATE</p> <p>APRIL 2001</p> <p>TO PRESENT</p>	<p>DATE ISSUED</p> <p>12/01/10</p>	<p>DRAWING NUMBER</p> <p>9955-013-003</p>
		<p>DATE REVISED</p>	