



Option -FTA



Flood-trol Auto-Reset -

This option eliminates the requirement to manually reset the Flood-trol valve assembly by substituting a float tank for the reset button assembly. Flush valve becomes operable automatically after the flood condition has been corrected.

Please visit www.acorneng.com for most current specifications.

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

