

SLAB Shower Base:

CSB3636

CSB3636ADA

CSB6030

CSB6030ADA

SLAB SOLID SURFACE
SHOWER BASE



Model Shown: CSB3636ADA

SLAB SHOWER BASES

SLAB SOLID SURFACE SHOWER BASES RECOMMENDED CLEANING & MAINTENANCE PROCEDURES

Acorn's Corterra Solid Surface material is composed of Cast Polyester Resin, Aluminum Trihydrate and Fillers. It is resistant to stains, impacts and burns. Complies with ANSI Z124.3.

Wash with a non-abrasive all-purpose cleaner and rinse with water. Wipe dry. *Never use cleansers with strong chemicals such as toilet bowl cleaners, rust removers, ceramic cooktop cleaners, paint or varnish removers, drain cleaners, metal cleaners, laquer thinners or oven cleaners.*

Surface damage, such as minor chips, scratches, burn marks and graffiti can be repaired with a fine grit abrasive cleaner, a Scotch-Brite pad or fine grit sandpaper. For more serious physical damage caused by vandalism, an Acorn Solid Surface Repair Kit is available. Contact factory for details.

NEO-METRO® by ACORN®



Acorn Engineering Company
15125 Proctor Ave. • City of Industry, CA 91746 USA
TF 800.488.8999 • PH 626.336.4561 • FX 626.961.2200

1 HANDLING

Carefully remove **Base** from packaging prior to installation. Inspect for any damage. Avoid placing **Base** on its edges; this precaution will prevent damage to corners.

REMOVE SHOWER BASE CAREFULLY FROM PACKAGING



REMOVE PACKAGING WITH CARE




AVOID STANDING BASE ON EDGES

2 LEVELING

Level **Base** carefully. For proper installation, establish a 1/4" maximum clearance between the **Base** and the walls. Place up to 1/2" of Mortar or Thinset and screed in area where the **Base** is to be installed. This procedure is recommended in order to support the **Base** should the Sub-Floor be uneven. Taper the Mortar/Thinset to a 1/4" thickness around the Drain Floor. DO NOT place Mortar/Thinset closer than 2" from the edge of the **Base** or the Floor Drain opening.




DOTTED AREA IS FOR CORTERRA BASE



3 WARNING!

DO NOT DROP BASE OVER EXPOSED PIPE

It is advisable to remove Drain Pipe prior to setting **Base** in place. Insert Pipe through Drain in **Base** into P-Trap. Tighten with an Internal Pipe Wrench.







REMOVE PIPE FROM P-TRAP

RE-INSERT PIPE AND TIGHTEN WITH AN INTERNAL WRENCH

4 DRAIN AND WASTE INSTALLATION:

1. Remove Drain Grate and assemble Drain Body to Corterra **Base** and tighten Locking Nut to affix Drain to **Base**.
2. Cut & dry-fit Waste Pipe to 1/2" below bottom of shower base.
3. Position Corterra **Base** over 2" IPS Waste Pipe assembly and ensure the Pipe is centered in the Drain Body. Use a Carpenter's Level to ensure base is level. Base should be evenly supported.
4. Lubricate Gasket with soap solution and stretch over 2" Pipe with beveled edge and push Gasket as far as possible into joint.
- 5A. Thread Caulking Nut with Wrench provided to secure Drain to Pipe.
- 5B. Use Screwdriver if necessary.
6. Test connection before covering or concealing. To test: Plug Drain and fill Receptor with water. Check for leaks. **This must be done before finishing walls.**
7. Attach Drain Grate and Strainer to Drain Assembly.




5 RECOMMENDED INSTALLATION FOR MODEL WITH TILING FLANGE OPTIONS:

1. Allow the Rough Wall material with a gap of approximately 1/2" (Do not allow Rough Wall Material to overlap Tiling Flange)
2. Let Finished Wall (Tile, etc.) overlap and rest on shoulder.


NOTE: Neo-Metro assumes no responsibility for problems due to faulty installation or inadequate floor support.

DO NOT NAIL OR SCREW FLANGE TO WALL



STEP 1:

LATH / PLASTER BOARD, ETC.



STEP 2:

FINISHED WALL MATERIAL (Tile, etc.)

